

INSTALLATION INSTRUCTIONS

Wall coping, wall coping ending and rough-hewn wall coping.

Material to be used:

Any model of Wall coping: double-beveled (AL-), slab (LO-), sloping (UP), or U-shaped Wall coping
Wall coping ending (TAL-, TLO-)
Rough-hewn Wall coping (CLAL-./CLLO-)

Recommended products:

Install with type B mortar.
COLA-SAS for pointing the joints.
SAS-FUGUE to protect the whole unit and guarantee optimal piece aging.
Silicon for sealing expansion joints.

Installation:

Wet the pieces by soaking them in water for 2 hours, and then remove them and leave them to drain for 10 minutes before installation.

Use type B mortar for installation. After 4 hours point with COLA-SAS tile cement. Stick adhesive tape to both sides of the joint to avoid staining the parts.

Precautions to be taken into account:

Point the joints with COLA-SAS tile cement. Allow 4 or 5 hours to pass and clean with a brush and damp cloth.

One week later, if dry, the whole unit should be painted with our SAS-FUGUE colourless surface waterproof sealant to afford it extra protection and optimal piece aging.

