

INSTALLATION INSTRUCTIONS

“Centenari” slabs.

Preparation before installing:

- It is indispensable to compact the base on which we are going to install the “CENTENARI” slabs. If it is a mortar base wet it before installing.
- If installing more than one pallet of “CENTENARI” slabs, mix the pieces.
- The “CENTENARI” slabs pieces will be installed wet, and should be soaked in water for 2 hours, and taken out 10 minutes before installation.

Material to be used:

“CENTENARI” slabs, SAS-FIX, M-40 mortar

Recommended products:

Install the slabs with type A mortar.
Seal joints with SAS-FIX.

Installation:

1. Install the slabs on a bed of type A mortar at least 6 cm thick.
2. The slabs should be installed “full in”, without leaving joints, and making sure that the latter do not leak and are clean. Allow for

expansion joints every 50 m² or for sections of more than 6 linear metres.

3. Wet the flooring every 5 / 6 m². When you have finished cover the area with a tarpaulin or canvas/plastic and leave it to dry for at least 2 days before sealing the joints.

4. One week later, if dry and dust-free, it should be painted with our SAS-FUGUE colourless surface waterproof sealant to afford it extra protection and guarantee optimal piece aging.

Joint sealing:

- To get the best possible finish the joints can be sealed, thus achieving an unbeatable rustic finish.
- Use our SAS-FIX mortar.
- Once the “CENTENARI” SLABS have been installed clean the joints, which should be free of loose parts, oils, grease, etc.
- Do not seal while the parts are still wet or damp.

Precautions to be taken into account:

- Make a diagram with the exact measurements and co-ordination chosen.
- Do not install on freezing or very hot days.
- Wet the flooring installed at the end of the day and for two further days.
- Do not seal joints on rainy or very damp days.
- Make sure that the base is well compacted.

