

INSTALLATION INSTRUCTIONS

Chimney vents

Recommended products:

COLA-SAS to join the pieces that make up the static vent. SAS-FUGUE to prime the Pillar Cap or covers of the vent to get better waterproofing.

Installation:

- The CHIMNEY VENTS are manufactured in two formats, ROUND AND SQUARE, and can be adapted to all types of flues, thus taking conducts of up to 31 x 31 cm. for Square ones and 31 cm. for the Round ones.
- The CHIMNEY VENT we suggest comprises a base piece, 4 intermediate pieces and a Pillar Cap or cover. To improve the flue, increase the number of intermediate pieces to a maximum of 6 units. These pieces fit perfectly as they are male and female parts

and their measurements are exact, thus guaranteeing perfect fit and anchoring.

- Install the flat PILLAR CAP, model CK-50 IM or CK-38 IM as static vent cover, which has a water drip at the bottom ends and protects the vents from the damp.
- The base piece also has a water drip to protect the chimney in bad weather conditions.
- There are several base piece models.
- Use our COLA-SAS to install the pieces.

Precautions to be taken into account:

- You must prime the cover with SAS-FUGUE to achieve optimal waterproofing if you are not using an "IM" element.
- The static vents should never be dry-mounted. They must be joined with tile cement, mortar, epoxy resin, etc.

