

INSTALLATION INSTRUCTIONS

Concrete supports.

Preparation before installing:

Pieces: A-3, A-4, A-5, B-6, C-6.

Our TE-40, TE-50 and TEG-500 terrazzo models are the perfect complement for the supports.

Installation:

The SAS SUPPORTS provide a practical solution as they can be easily dry-mounted.

As it a workable flooring, it can be used to house any utilities we need (electricity wires, irrigation pipes..., etc.).

The use of different models of pieces provides a perfect graduation of support height, allowing for heights of up to 70 cm. The minimum height is 3 cm, the thickness of model A-3. Begin by installing the base piece C-6, and then add intermediate pieces B-6, and then to level off to the required height with mortar or sand filling and the top pieces A-3, A-4 or A-5, which measure 3, 4 and 5 cm, respectively.

Precautions to be taken into account:

The loads admitted by the supports are very high, although they are normally limited by the strength of the terrazzo.

