

INSTALLATION INSTRUCTIONS

Collection boxes.

Preparation before installing:

The collection boxes must be installed on a 6-cm-thick mortar slab or on a duly compacted base.

Material to be used:

- The ARG-40 and ARG-50 elements are complements for the RG-40 and RG-50 collection boxes, respectively, which permit supplements in order to achieve the required height so that they can be inspected from ground level.
- Each collection box model has a self-fitting inspection cover (TRG-30, TRG-40, TRG-50).
- The 40x40 and 50x40 cm collection boxes can be used as siphon traps, with the advantage that this entails, thanks to the siphon model SRG-40 y SRG-50.

Installation:

We make three sizes of collection boxes (30x30, 40x40, 50x40 cm) which can be used as a link between the leader pipes and waste pipes or as inspection traps.

The collection boxes must be installed on a 6-cm-thick mortar slab. Connect the pipes to the collection box and fill the sides with gravel so that it is secure.

The sides of the collection box have cut-outs into which the pipes fit. The cut-outs must be broken (when necessary) with care, with the help of a chisel and a hammer and from the centre to the perimeter of the cut-out.

Precautions to be taken into account:

The cover should be accessible for inspection purposes and for extra convenience when carrying out maintenance work. Otherwise use the ARG-40 and ARG-50 supplements.

